

Lift Kit Installation Instructions



WARNING:

Disconnect electrical power to unit.

This lift kit is for those who wish to raise the wheel center higher above the table. The reason for this...there are fixtures on the market that are taller than Accu-Finish fixtures. This will allow the use of those fixtures.

TO INSTALL LIFT KIT

Remove the side bolts (one located each side) that hold the motor housing. Once you have the motor housing separated from the base, remove the bushings that the bolts were

placed through and the plastic plugs above the bushings. Now, place the bushings in the hole where the plastic plugs were and the plastic plug where the bushings were (see diagram below.)

Remove the bolts that hold the latch magnet from the center base. Turn the magnet brackets sideways and move the magnet to the top and replace the bolts (see diagram below.)

Remove the two rubber stops located at the back. Push the bolt out of the center of each and replace with the long bolt that come with the lift kit. Insert the long bolt through the plastic extensions and replace on base.

Reattach the motor housing unit to the side arms.

